

B2.5

DISTRIBUTION MODULE ASSEMBLY

KYT-070
11/2021

Update Notes

■ Contents

Tools&Equipment Informations

Tool Symbol Guide.....	4
Torque Table.....	5
Screw/Bolt/Special Parts for Assembly.....	6
1 Main Busbar Assembly	
1.1 4 Flat Bar Assembly (Top).....	7
1.2 2 Flat Bar Assembly (Top)	11
2 Vertical Busbar	
2.1 4 Flat Bar Vertical Bar Assembly (2500A-4000A).....	15
2.2 2 Flat Bar Vertical Bar Assembly (1350A-2300A).....	25
2.3 2 Flat Bar Vertical Bar Assembly (495A-1300A).....	35
3 Earthing Bar Assembly.....	41
4 Top Cover Assembly.....	43
5 Rear Panel Assembly	44
6 Fixed Front Cover Assembly.....	46
7 Side Panel Assembly.....	47


 Tools Symbol Guide




Cross




Slot




M4 Allen Key




M8 Allen Key




M5 Allen Key



M10 Allen Key




M6 Allen Key




M3 Spanner



M6 Spanner



M12 Spanner




M4 Spanner




M8 Spanner



M18 Spanner



M5 Spanner



M10 Spanner

Caution: For safety precaution ; Protective gloves and equipments must be used while assembly.

As additional tools for assembly;

- Torque wrench features:
 - ✓ Tightening torque : 75 N.m
 - ✓ It has a reduced thickness, can be easily used to access non accessible joints/fishplates and between busbars.
- Torque wrench an accessories:
 - ✓ Wrench shaft - mandatory
 - ✓ Extra-thin pawl adapter - mandatory
 - ✓ Pawl for ordinary sockets
- Extra-thin sockets for pawl + shaft:
 - ✓ 13 mm extra-thin low socket
 - ✓ 13 mm extra-thin high socket
 - ✓ 15 mm extra-thin low socket
 - ✓ 15 mm extra-thin high socket
 - ✓ 18 mm extra-thin low socket
 - ✓ 18 mm extra-thin high socket

■ Torque Table for Screw/Bolt

Recommended tightening torque for mechanical and electrical links 8.8-class screws (with nut + washers)	
Diameter of Screw	Tightening Torque (N.m)
M3	1.5
M4	3.5
M5	7
M6	13
M8	28
M10	50
M12	75

Tightening torque for electrical links on the devices and for their fixing:

Marking varnish:

After tightening each electrical connection to the appropriate torque, apply some varnish:

- ✓ Between the nut and the screw or
- ✓ Between the screw head and the copper bar or
- ✓ Between the device for tightening on a threaded part

Varnish should not block the screw:


- ✓ It allows operator inspection, to verify if the bolts/ nut are tightened or not.
- ✓ It facilitates the identification of any loose nuts during the switchboard's lifetime.

Varnish features:

- ✓ Coloured acrylic varnish, indelible and able to resist a 150° C temperature.
- ✓ PDS recommends a red varnish as a standard to identify the panelbuilder's work.
- ✓ Other colours can be used by the contractor or any operators entitled to work on the switchboard after its commissioning.

■ Screw/Bolt/Special Parts for Assembly


Philips Pan
Head Screw




M6x23 Philips Flat
Head Screw (Teos)




M5x20 Philips Flat
Head Screw (Teos)



Philips Flat Head
Screw




Hexagon Socket Head
Bolt (Half Thread)




Hexagon Socket
Head Bolt




Hexagon Socket
Button Head Bolt




Hexagon Socket
Flat Head Bolt




Hexagon Head Bolt
(Half Tread)




Hexagon Head
Bolt



Internal Door
Knob Bolt




Regular Nut




Flange Nut



Previling Torque
Nut




Cage Nut



Plastic Cage
Nut




Flat Washer



Spring Lock
Washer



Toothed Lock
Washer







Wedge Lock
Washer





1. BUSBAR ASSEMBLY

1.1 FOUR (4) FLAT BAR ASSEMBLY (TOP)



Neutral Section	Rated Current (In)	Flat Copper Size (mm) xQty	
		L1/L2/L3	Neutral(N)
1/2 N	2500A	40/10x4	40/10x2
1/1 N	2500A	40/10x4	40/10x4
1/2 N	3000A	50/10x4	50/10x2
1/1 N	3000A	50/10x4	50/10x4
1/2 N	3400A	60/10x4	60/10x2
1/1 N	3400A	60/10x4	60/10x4
1/2 N	4000A	80/10x4	80/10x2
1/1 N	4000A	80/10x4	80/10x4

1.1 FOUR (4) FLAT BAR ASSEMBLY (TOP)



M10x H
8 pcs.






M10
8 pcs.

Required Packages:

1010.18X

1009.0XX/1011.XXX





■ 1.1 FOUR (4) FLAT BAR ASSEMBLY (TOP)




Required Packages:

1010.18X




1009.0XX/1011.XXX




M5X10

M8x20
1 pcs.M8
1 pcs.M8
1 pcs.


■ 1.1 FOUR (4) FLAT BAR ASSEMBLY (TOP)




1.2 TWO (2) FLAT BAR ASSEMBLY (TOP)




NEUTRAL L L L



NEUTRAL L L L




NEUTRAL L L L



Neutral Section	Rated Current (In)	Flat Copper Size (mm) xQty	
		L1/L2/L3	Neutral(N)
1/2 N	1350A	40/10x2	40/5x2
1/1 N	1350A	40/10x2	40/10x2
1/2 N	1620A	50/10x2	50/5x2
1/1 N	1620A	50/10x2	50/10x2
1/2 N	1860A	60/10x2	60/5x2
1/1 N	1860A	60/10x2	60/10x2
1/2 N	2300A	80/10x2	40/10x2
1/1 N	2300A	80/10x2	80/10x2


1.2 TWO (2) FLAT BAR ASSEMBLY (TOP)



Required Packages:

1010.16X


1009.0XX/1011.XXX/1019.0XX






M10x H
8 pcs.



M10
8 pcs.



If 1/2 Section Neutral Copper Bar thickness is 5mm, Adapter must be used.





■ 1.2 TWO (2) FLAT BAR ASSEMBLY (TOP)





Required Packages:

1010.16X




1009.0XX/1011.XXX/1019.0XX



M5X10

M8x20
1 pcs.M8
1 pcs.M8
1 pcs.


■ 1.2 TWO (2) FLAT BAR ASSEMBLY (TOP)





2. VERTICAL BUSBAR ASSEMBLY

2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)


4 Flat bar to 4 Flat Bar(65kA)



4 Flat bar to 4 Flat Bar (85kA)





2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)






M5X10

Required Packages:
1010.38X
1009.0XX/1011.XXX



■ 2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)

Required Packages:
1010.38X
1009.0XX/1011.XXX







2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)




M5X10


Required Packages:
1024.280



M8x12







M6x15




■ 2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)

Required Packages:
1024.280



M8x40




M8x20



M8





M8






■ 2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)

Required Packages:
1012.002/003/004




2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)


Required Packages:
1021.XXXX (1043.XXX)



2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)





Required Packages:
1009.0XX/1011.XXX



M10x H





M10



■ 2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)


Required Packages:
1021.XXXX






M10x H




M10



M10




2.1 FOUR (4) FLAT VERTICAL BAR ASSEMBLY (2500A-4000A)



Required Packages:
Std:1009.0XX/1011.XXX



Torque: 20Nm



M10x H



M10




Required Packages:
Top:1023.1XX





M5X10

Warning: This part must be use if main busbar is not continue.




2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)



4 Flat bar to 2 Flat Bar(65kA)




2 Flat bar to 2 Flat Bar(65kA)



2 Flat bar to 2 Flat Bar (85kA)





■ 2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)




M5X10

Required Packages:
1010.36X/1010.48X
1009.0XX/1011.XXX



■ 2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)

Required Packages:
1010.36X/1010.48X
1009.0XX/1011.XXX





M8x20
1 pcs.




M8
1 pcs.



M8
1 pcs.







2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)



M5X10


Required Packages:
1024.260/280



M8x12







M6x15



■ 2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)

Required Packages:
1024.260/280



M8x40



M8x20





M8



M8




■ 2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)

Required Packages:
1012.002/003/004




2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)


Required Packages:
1021.XXXX (1043.XXX)



2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)



Required Packages:
1009.0XX/1011.XXX





M10x H



M10







M10





■ 2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)

Required Packages:
1021.XXXX



2.2 TWO (2) FLAT VERTICAL BAR ASSEMBLY (1350A-2300A)





M10x H



M10

Required Packages:
1009.0XX/1011.XXX


Torque: 20Nm







M5X10

Required Packages:
Top:1023.1XX


Warning: This part must be use if main busbar is not continue.



2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)




4 Flat bar to 2 Flat Bar(5mm Copper)
(65kA)2 Flat bar to 2 Flat Bar(5mm Copper)
(65kA)

2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)




M5X10

Required Packages:
1010.48X
1009.0X6 / 1044.XXX






M8x20
1 pcs.



M8
1 pcs.




M8
1 pcs.






■ 2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)

Required Packages:
1024.260/280




M5X10








M8x12



M6x15






2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)



2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)


Required Packages:
1009.0X6 / 1044.XXX





M10x H






M10



M10



Required Packages:
1021.XXXX



M8x H




M8




M8

2.3 TWO (2) FLAT VERTICAL BAR ASSEMBLY (495A-1300A)



Required Packages:
1009.0X6 / 1044.XXX





M10x H





M10



M10




3. EARTHING BAR ASSEMBLY




Neutral Section	Rated Current (In)	Flat Copper Size (mm) xQty
		PE
1/2 N	1350A	20/5x2
1/1 N	1350A	40/5x2
1/2 N	1620A	25/5x2
1/1 N	1620A	50/5x2
1/2 N	1860A	30/5x2
1/1 N	1860A	60/5x2
1/2 N	2300A	40/5x2
1/1 N	2300A	40/10x2

Neutral Section	Rated Current (In)	Flat Copper Size (mm) xQty
		PE
1/2 N	2500A	40/5x2
1/1 N	2500A	40/10x2
1/2 N	3000A	50/5x2
1/1 N	3000A	50/10x2
1/2 N	3400A	60/5x2
1/1 N	3400A	60/10x2
1/2 N	4000A	40/10x2
1/1 N	4000A	80/10x2

3. EARTHING BAR ASSEMBLY








Required Packages:
1012.0XX



M8x25/35





M5X10





4. TOP COVER ASSEMBLY

Warning: This assembly step must be applied after cassette assembly (internal part assembly).





M12x30
4 pcs.

Without Baying Kit



With Baying Kit





5. REAR PANEL ASSEMBLY



M5X10

Warning: This assembly step must be apply after cassette assembly (internal part assembly).

Required Packages:
1003.X20





5. REAR PANEL ASSEMBLY



Required Packages:
1003.X20



M6x23
8 pcs.



6. FIXED FRONT COVER ASSEMBLY









M8x12
8 pcs.



M5X10
8 pcs.

Required Packages:
1020.X20




7. SIDE PANEL ASSEMBLY

Required Packages:

Side Panel:706.2XX

Busbar Protection:1023.1XX



M6x23
8 pcs.



M5x25
1 pcs.

M5x25 Only for 800

